

PART NUMBERING SYSTEM FOR PRODUCTS ON PAGES 3 TO 35 OF THIS CATALOG

| A | | | A | | | B | | | B-C | | D | | E | | F | |
|-------|-------|-----------------------|-------|-------|------|-------|---------|-------|-------|-------|-------------------------------------|-------|------------------------------------|--|---|--|
| DIGIT | DIGIT | MODEL NO. | DIGIT | DIGIT | SIZE | DIGIT | VOLTS | DIGIT | BORE | DIGIT | DRIVE | DIGIT | CONNECTION | | | |
| 1 | 7 | FSB | 0 | 1 | 001 | 1 | 90 VDC | 1 | 1/8 | 1 | ZERO BACKLASH | 1 | LEAD WIRES | | | |
| 1 | 9 | FSBR | 0 | 2 | 003 | 2 | 24 VDC | 2 | 3/16 | 2 | HEX/SQUARE | 2 | SCREW TERMINALS | | | |
| 2 | 1 | FSBR (MANUAL RELEASE) | 0 | 3 | 007 | 3 | 12 VDC | 3 | 1/4 | 3 | DYNAMIC (MANUAL RELEASE BRAKE ONLY) | 3 | SWITCH (MANUAL RELEASE BRAKE ONLY) | | | |
| | | | 0 | 4 | 015 | 4 | 120 VAC | 4 | 5/16 | 4 | STATIC (MANUAL RELEASE BRAKE ONLY) | 4 | CONDUIT BOX | | | |
| | | | 0 | 5 | 035 | | | 5 | 3/8 | 5 | SPLINE | | | | | |
| | | | 0 | 6 | 050 | | | 6 | 1/2 | | | | | | | |
| | | | 0 | 7 | 100 | | | 7 | 5/8 | | | | | | | |
| | | | 0 | 8 | 200 | | | 8 | 3/4 | | | | | | | |
| 0 | 1 | SL | 0 | 9 | 08 | | | 9 | 7/8 | | | | | | | |
| 0 | 3 | BSL | 1 | 0 | 11 | | | 0 | 1 | | | | | | | |
| 0 | 5 | FL | 1 | 1 | 15 | | | 11 | 1 1/8 | | | | | | | |
| 0 | 7 | SO | 1 | 2 | 17 | | | 12 | 1 1/4 | | | | | | | |
| 0 | 9 | FO | 1 | 3 | 19 | | | 13 | 1 3/8 | | | | | | | |
| 1 | 1 | FB | 1 | 4 | 22 | | | 14 | 1 1/2 | | | | | | | |
| 1 | 3 | SLB | 1 | 5 | 26 | | | | | | | | | | | |
| 1 | 5 | SOB | 1 | 6 | 30 | | | | | | | | | | | |
| | | | 1 | 7 | 42 | | | | | | | | | | | |
| 1 | 8 | SAB | 1 | 8 | 20 | | | | | | | | | | | |
| | | | 1 | 9 | 90 | | | | | | | | | | | |
| | | | 2 | 1 | 180 | | | | | | | | | | | |
| | | | 2 | 3 | 400 | | | | | | | | | | | |
| | | | 2 | 5 | 1200 | | | | | | | | | | | |

How To Order

- A. Select the model number from the product guide.
- B. Select the size of the clutch or brake.
- C. Select the voltage.
- D. Select the bore diameter.
- E. For all power-on clutches and brakes, select 1. For model FSBR and SAB-20, & 90, select 2. For model FSB spring applied brakes, select 1 or 2. For manual release brakes, select 3 or 4. For SAB-180, 400, & 1200, select 5.
- F. For all clutches and brakes, refer to the product guide and specify 1 or 2. For manual release brakes, if a switch is desired, select 3, otherwise use a 1.

Example

SL11 clutch, 24 volts, 1/4" bore
 Part No. 0110-2311
 FSB050 brake, 90 volts, 3/8" bore, Hex drive
 Part No. 1706-1521