


## Electromagnetic Power-On Friction Clutches & Brakes

### PART NUMBERING SYSTEM FOR PRODUCTS ON PAGES 5 TO 28 OF THIS CATALOG



#### How To Order

- Select the model number from the product guide.
- Select the size of the clutch or brake.
- Select the voltage.
- Select the bore diameter.
- For all power-on clutches and brakes, select 1.
- For all clutches and brakes, refer to the product guide and specify 1 or 2.

#### Example (Imperial)

SL11 clutch, 24 volts, 1/4 bore  
Part No. 0110-2311

#### Example (Metric)

FB11 brake, 24 volt D.C., 6mm bore  
Part No. M1110-2211

